
# Ergste<sup>®</sup> 9.9200GA Magnetizable | Hardenable Datasheet Medical Alloys

# zapp

# Zapp is Certified to ISO 9001



# Material Ergste® 9.9200GA

Ergste<sup>®</sup>9.9200GA is a precipitation hardenable 12% chromium nickel steel with outstanding corrosion resistance and impact toughness. Despite high strength this quality can be formed relatively well. By appropriate cold forming / heat treatment is a hardness of max. 51 HRC\* to reach.

\* maximum achievable hardness under ideal hardening conditions

# **Typical Fields of Application**

- Surgical instruments (e.g. drills)
- Cutting instruments (e.g. rasps)

#### Magnetism

Ergste® 9.9200GA is magnetizable.

#### Weldability

Easily welded with fusion welding (e.g. MIG, TIG) and resistance welding; ideally in the solution condition. Preheating is not necessary. Gas fusion welding with oxygen-acetylene flame should be avoided, as this may cause it to carburization.

#### **Cold Working**

For massive cold working the solution-annealed condition (condition A) shall be ordered.

# **Corresponding Standards**

• No corresponding description

#### Typical Chemical Composition \*

С	Mn	Cr	Ni	N	Ti	Мо	
< 0.030	0.20	12.00	8.90	<0.030	1.60	2.00	

\* Average in mass-%

#### **Mechanical Properties\***

Condition	Tensile strength Rm [MPa]	Yield strength Rp <sub>0,2</sub> [MPa]	Elonga- tion A [%]	Reduction of area Z [%]	Hardness HRC/HB
A	1,070	890	10	66	35.0
H900	1,890	1,770	5	20	51.5
H950	1,850	1,730	6	40	50.5
H1000	1,690	1,490	8	50	48.8
CW full hard + aged	2,730	2,700	1	-	-

\* Average values

#### **Physical Properties**

[GPa]	200
[kg/dm³]	7.81
[W/m*K]	15.83
[10 <sup>-6</sup> *K <sup>-1</sup> ]	10.3 10.8 10.9 11.1 10.9
[kJ/kg*°C]	-
$[\Omega^*mm^2/m]$	0.82
	[kg/dm <sup>3</sup> ] [W/m*K] [10 <sup>-6*</sup> K <sup>-1</sup> ] [kJ/kg*°C]

# Hot Working

Forging at 1,010 – 1,093 °C The final temperature should be in the range 820 -930 °C, in order to adjust the optimal grain size and properties after hot working. Slow cooling in air. Forgings must be solution treated prior to precipitation hardening.

# Heat Treatment

Cooling: Air


# Solution Annealing

Temperature: 980 ± 15 °C Cooling: Furnace, air

# Precipitation Hardening

Temperature: 480 – 540 °C Holding time: ca. 4 h (depending on material mass)

### Tempering Chart



#### **Corrosion Resistance**

Better corrosion resistance than 1.4542 (UNS S17400) and 1.4543 (UNS S45500). Ergste® 9.9200GA shows good corrosion resistance in normal air atmosphere and no corrosion in fresh water.

#### Zapp Precision Metals GmbH

MEDICAL ALLOYS Letmather Straße 69 58239 Schwerte P.O. Box 17 20 58212 Schwerte Phone +49 2304 79-540 Fax +49 2304 79-482 medicalalloys@zapp.com

www.zapp.com

Further information regarding our products and locations are available in our image brochure and under www.zapp.com

The illustrations, drawings, dimensional and weight data and other information included in this data sheet are intended only for the purposes of describing our products and represent non-binding average values. They do not constitute quality data, nor can they be used as the basis for any guarantee of quality or durability. The applications presented serve only as illustrations and can be construed neither as quality data nor as a guarantee in relation to the suitability of the material. This cannot substitute for comprehensive consultation on the selection of our products and on their use in a specific application. The brochure is not subject to change control. Last revision: July 2020